



# JIB HEAD ADAPTER OPERATION AND SAFETY GUIDE

SLINGCO PART NO. ZWH1091

## ⚠ ATTENTION

**READ** and **UNDERSTAND** all of the instructions and safety information in this manual before operating or servicing this tool.

Failure to read and understand these warnings and safe handling instructions could result in severe personal injury or death.

**KEEP THIS MANUAL WITH TOOL.**



Pinch Point Warning



Safety Goggles Required



Hard Hat Required



Suspended Load



Electrical Shock Hazard



Insulated Gloves Required

## SAFETY & MAINTENANCE

### WORK AREA SAFETY

1. Keep the area around the equipment clean and free of obstruction.
2. Bystanders should stay clear of the work area to ensure safety.

### PERSONAL SAFETY

1. Stay alert while using the equipment to prevent serious injury. Do not use under the influence of drugs, alcohol or medications.
2. Do not wear loose hair or clothes that may get caught while the equipment is in operation.
3. Work safely. Maintain your balance and do not reach while operating equipment.

### TOOL USE AND CARE

1. **DO NOT** use this tool if there are any abnormalities or damage to any of its components.
2. Inspect the tool before and after every use. Do not use this tool if it is damaged in any way.

## WARNINGS

- Inspect Jib Head Adapters before and after each use. Pay close attention to all weldments, inspecting for cracks and/or rust. If there is any damage, discard the product immediately.
- Temporary items are intended to be inspected frequently. Follow your company's standard work practices or inspect routinely.
- Only Slingco pins should be used with this tool.



**Slingco America, Inc.**  
130 Celtic Blvd, Tyrone,  
Georgia, 30290, USA  
TOLL FREE: 888 685 9478  
sales@slingcoamerica.com

**888-685-9478**

**slingco.com**

Jib Head Adapter Operation and Safety Guide: MAN13547 – RevA Date March 2024

**Slingco Limited**  
Gateway Business Park, New Hall Hey Road,  
Rawtenstall, BB4 6JG, England  
Tel: +44 [0]1706 855558  
sales@slingco.com

**+44 [0]1706 855558**

**Slingco Australia Pty. Ltd.**  
L9, 1 York Street, Sydney,  
NSW 2000, Australia  
Sales: +61 3 8840 6556  
sales@slingcoaustralia.com.au

**+61 3 8840 6556**

## ATTENTION

**DO NOT** perform any service or maintenance on this tool other than described in this manual.  
Read and follow the operator's manual before using this tool.  
This manual should be kept available to all operating and maintenance personnel.

## DESCRIPTION

- Manufactured from zinc plated steel.
- Supplied with machined pin and lanyard.
- For mounting Jib Head attachment and assemblies.
- Dimensions: 4.1 x 4.1" (104.1 x 104.1 mm).

